



1271 KING ROAD, P.O. BOX 507  
BURLINGTON, ON L7R 3Y3  
T. 905.634.2365 F. 905.333.3521

---

## INSTALLATION

### REQUIRED SUPPLIES AND TOOLS:

#### SUPPLIES

- 3/8" Plywood Setting Blocks
- 6"-9" Self-Adhered Flashing \*Must be self-sealing for fastener penetrations.
- Fasteners (#8 x 2 1/2" finishing screw recommended)
- Foam Backer Rod
- Low Expansion Spray Foam
- Good Quality Exterior Grade Sealant
- Shims

#### TOOLS

- Caulking Gun
- Hammer/ Mallet
- Level
- Pry Bar
- Screw Gun or Drill
- Square
- Tape Measure
- Utility Knife